



EXPERIENCE TO PERFORM

TECHNICAL DATA SHEET

NEO BIOCID

DISINFECTANT AND GERMICIDE WITH BACTERICIDE AND FUNGICIDE ACTION

- PRODUCT DESCRIPTION

Disinfectant and deodorant spray for rooms and surfaces that combats bacteria and fungi. Perfect for disinfecting the passenger compartment of cars, trucks, buses, minivans, campers and mobile homes (total drainage mode); hospital wards, clinics, classrooms and offices (manual dispensing mode). The product does not stain.

- TECHNICAL SPECIFICATIONS

- Physical condition Aerosol
- Color Colorless
- Odor Mint
- Specific weight 0.610 g/cm³

- METHOD OF USE

For disinfecting the interiors of cars, trucks, buses, minivans, campers and mobile homes: carefully clean the passenger compartment and ensure that the cigar lighter is not in operation. Open drawers, storage compartments, air vents and close windows. With the engine running, turn the air condition on full, activating recirculation mode and the fan at maximum speed, where necessary removing the pollen filter. Shake the can before use and place it on the floor at the center of the passenger compartment. Press down the button until it is locked in the position of total drainage, leave the compartment and close the doors. Wait for the can to be drained completely and leave to act for at least 15 minutes. Before opening the passenger compartment, ventilate it by opening the doors and removing the residues with a clean cloth.

Manual dispensing mode:

gently press the dispenser button, taking care not to lock it in the total draining position. Dispense and evenly cover the surfaces to be disinfected, leaving the product

to act for at least 15 minutes. Remove the residue with a clean cloth. Repeat.

- WARNINGS

Once the treatment is complete, ventilate the space before entering. Do not use the product in the presence of flames or sparks. Do not contaminate food, drinks or their relative containers/bottles. Do not inhale the spray and do not spray in the eyes.

- STORAGE

The batch number and date of manufacture are indicated on the bottom of the can. Unopened and stored at room temperature away from direct sunlight:
valid for 24 months

- PACKAGING

Packaging: metal spray can

Code 4155 150 ml

- NOTES

For information on product safety, please consult the safety sheet.



**Registered with the Ministry of Health as a
Medical Surgical Device, under number 19440**

T.S 15.03.2018

The data contained herein are the result of technological research by our laboratories and are given for informative purposes only. We exclude any liability deriving from the incorrect choice or application of the product and from the lack of the necessary precautions, which should be carefully checked by the user. For information, please contact our Technical Dept. on no. +39 02924361

AREXONS S.p.A. A SOCIO UNICO
Via Antica di Cassano, 23
20063 Cernusco sul Naviglio (MI) Italy
Capitale Sociale: € 15.000.000,00 I.V.
Registro delle Imprese di Milano n. 09728360968
Codice Fiscale e Partita IVA 09728360968
Direzione e coordinamento ex art. 2497 c.c. PLI (Netherlands) B.V.
Centralino 02 92436.1
Fax 02 92436.306
www.arexons.com

A wholly-owned subsidiary of PETRONAS

Sistemi di gestione di qualità della società Arexons S.p.A.
certificati ISO 9001 da LRQA.

Sistemi di gestione di ambiente e sicurezza della società Arexons S.p.A.
certificati ISO 14001 e OHSAS 18001 da Bureau Veritas.

